

# LG V60

## Installation

### 1 Tools & Parts Needed



2 Place P21005 Power Coupler into VP-1431C Clip. Attach factory magnetic power clip. Adhere the AD-51 Adhesive onto the middle of the case.



Remove adhesive liner from the AD-51. Place the device into the folding case and into the charging connector and snap into place.



Remove the adhesive liner from the bracket. Attach the magnetic clip onto the charging port of the phone. Adhere the VP-1431C clip onto the case.



Plug the P21005 Power Coupler into the sensor.



Adhere the AD-218 Clear Adhesive over VP-1431C Clip and onto the phone case.

# LG V60

## Installation

7



Remove the adhesive liner and adhere the sensor to the center of the case.

8

Attach the sensor to the pedestal by rotating the boot onto the sensor.

Arm the system with your IR Key.



9

### Night Removal

1. Disarm the CR361 with the keyfob aimed at the pedestal's IR window
2. Use magnet tool to remove the boot from the sensor.
3. Aim keyfob at bottom of sensor and long-press the disarm/lock button for approximately five seconds to power down the sensor.
4. Store the device, with sensor attached, securely overnight

10

