

SLIM WEARABLE SENSOR

Installation

click or scan QR code
for installation video



1 Tools & Parts Needed

	Stands		Cradles		V-T900
	VP-1625 Generic		VP-1635 Samsung Or		V-T99
	Or		VP-1656 Garmin Or		V-37
	VP-1559 Apple		VP-1657 Generic Or		VP-1626
	Alarms		VP-1664 Galaxy Active Or		VP-1636
	VP-1397W		VP-1689 Mont Blanc Or		VP-1433M
			VP-1694 Gizmo		

2 Thread the watch charger through the stand as shown.



3 Insert the watch stand into the bottom of the black Wearable Riser box. Thread the watch sensor cable through the watch stand and riser as shown.



Install the Wearable Riser's base plate with the 4 Phillips head screws.

SLIM WEARABLE SENSOR

Installation

click or scan QR code
for installation video



- 5** Use the appropriate watch cradle for the product you wish to secure.



Apply the circular adhesive to the back of the watch puck. Thread the watch charging cable through the watch cradle for the specified device. Remove adhesive liner and adhere the charging puck inside the cradle.

- 6** Insert the provided binding screw into the watch cradle.



Screw the watch cradle to the watch stand with the security driver (V-T900).

- 7**

Loosen the screw on the top of the Slim Wearable Sensor (VP-1626) and remove the clear shunt plug on the side of the sensor.

Insert the Flex Sensor (VP-1636) into the sensor.



- 8**



Close the Slim Wearable Sensor onto the top watch band and tighten with the security driver.

- 9**

Remove adhesive liner and adhere the Flex Sensor to the back of the watch head.

Ensure the Flex Sensor will not be crimped when the watch is placed on the display stand or fixture.



- 10**

For the Apple Watch Cradle, remove the rubber padding if using a 42mm Apple Watch or larger.



Rest the watch on the stand, and plug the sensor into the EnCore alarm unit (VP-1397).

IMPORTANT: If the Flex Sensor is damaged or missing, do **NOT** plug sensor into EnCore.